




Australian Government
Department of Agriculture
and Water Resources

Machinery Cleaning Guide - M Motor Graders Series 2

Biosecurity

Publication series

April 2016



DISCLAIMER

The information provided in this guide merely aims to assist machinery importers meeting the import conditions. This guide is not exhaustive and the Department of Agriculture and Water Resources makes no warranties or representations with respect to the accuracy or completeness of that information and will bear no liability with respect to that information. Importers must satisfy all biosecurity concerns and comply with biosecurity conditions applicable at the time of entry. The Commonwealth through the department is not liable for any costs arising from or associated with decisions of importers to import based on conditions presented here which are not current at the time of importation. It is the importer's responsibility to verify the accuracy and completeness of the information at the time of importation.

Inquiries regarding this document should be directed to:

Department of Agriculture and Water Resources
Machinery Team
PO Box 222
Hamilton QLD 4007

Within Australia Phone: 1800 900 090
Outside Australia Phone: +61 7 3246 8706
Email: machinery@agriculture.gov.au




© April 2016



The Department of Agriculture and Water Resources



This work is copyright. Apart from any use as permitted under the *Copyright Act 1968*, no part may be reproduced by any process without written permission from the First Assistant Secretary, Compliance Division, Department of Agriculture and Water Resources.

Information in this document is correct at time of publishing. Biosecurity conditions may change without notice. Please contact the Department of Agriculture and Water Resources to confirm details.

Cleaning guidelines

Description	Images
<p>In this image you can make out where the goose neck has been sealed off with a weld (red arrow) under the cover plate.</p>	
<p>Red arrows highlight the flush holes for the front of the goose neck. The green arrow and checkers highlight how far back the goose neck has been sealed.</p>	
<p>Red arrow shows the first flush hole on the front of the goose neck.</p>	

Description	Images
<p>In these images is the second flush hole at the front of the goose neck. The red arrow highlights that the flush hole is behind the stabiliser bar. The purple arrow shows the flush hole.</p>	
<p>The purple arrow highlights where access is to flush the rear of the goose neck. The red arrow and checkers show where the goose neck is sealed off.</p>	

Description	Images
<p>The red arrow shows a mirror being used to see if the goose neck is sealed off or open.</p>	 <p>A close-up photograph showing a person's hand holding a red-handled mirror. The mirror is positioned to reflect the interior of a yellow machine's goose neck. A red arrow points to the reflection area.</p>
<p>In these images the red arrow is asking you to look at the mirror. The blue arrows are showing where the goose neck is sealed off. Note the double plate and the small gap (green arrow).</p>	 <p>Two close-up photographs of the goose neck seal. The top image shows a blue arrow pointing to a double plate, a green arrow pointing to a small gap, and a red arrow pointing to the mirror. The bottom image shows a blue arrow pointing to the seal, a green arrow pointing to the gap, and a red arrow pointing to the mirror.</p>